

# ***ELK-751 & 752***

## ***MANUAL TRANSFER***

### ***STRETCHER***



## ELK-751 Manual Transfer Stretcher



- A type of manual transfer stretcher. Single crank for height adjustment. Turn by clockwise, stretcher will be up; Turn by anti-clockwise, stretcher will be down.
- Bright arrow symbols direct the user how to operate clearly
- Central-lock castors, diameter 150mm. Matched with direction castor under the chassis, help user easy control the stretcher direction
- **Dimension:**  
Overall dimension: 2050\*710mm(L\*W)  
Height adjustment(Bed board to ground): 875-570mm  
Size of bed board: 1900\*610mm(L\*W)  
Back-rest lifting angle: 0-60° ± 5°
- Drop-down protective railing, PP bed board produced by blowing molding
- Net Weight: 82kg
- Standard accessories: Mattress, I.V. pole



## ELK-752 Manual Transfer Stretcher



- A type of manual transfer stretcher. Single crank for height adjustment. Turn by clockwise, stretcher will be up; Turn by anti-clockwise, stretcher will be down.
- Bright arrow symbols direct the users how to operate clearly
- Central-lock castors, diameter 150mm. Matched with direction castor under the chassis, help users easy control the stretcher direction
- **Dimension:**  
Overall: 2050 710mm(L\*W)  
Height adjustment(Bed board to ground): 875-570mm  
Size of bed board: 1900 610mm(L\*W)  
Back-rest lifting angle: 0-60° ± 5°
- Four pieces drop-down protective railing. PP bed board produced by blowing molding
- Net Weight: 84KGS
- Standard accessories: Mattress, I.V. pole

